




































| Original  | Replacement   |
|---|---|
|  Power   |  Power   |
|  Mute    |  Mute    |
|  Display |  Info    |
|  Exit    |  Exit    |
|  TV / AV |  AV      |
|  SYS     |  Smart   |
|  1       |  1       |
|  2       |  2       |
|  3       |  3       |
|  4       |  4       |
|  5      |  5      |
|  6     |  6     |
|  7     |  7     |
|  8     |  8     |
|  9     |  9     |
|  0     |  0     |
|  -/--  |  Guide |

| Original  | Replacement  |
|---|--|
|  Recall  |  Pre Ch         |
|  V +     |  Vol +          |
|  V -     |  Vol -          |
|  P +     |  Ch +           |
|  P -     |  Ch -           |
|  Up      |  Up             |
|  Left    |  Left           |
|  Menu    |  Menu           |
|  Menu    |  Ok             |
|  Right   |  Right          |
|  Down   |  Down          |
|  SMode |  Format       |
|  PMode |  Shift + Dual |
|  Sleep |  Sleep        |
|  Nicam |  Dual         |
|  Hold  |  Stop         |
|  Index |  Media        |



