






































































Original	Replacement	Original	Replacement
 Power	 Power	 Exit/Back	 Exit
 Mute	 Mute	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 P+	 Ch +
 6	 6	 P-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 [<<>>]	 Format
 0	 0	 TV/R	 TV/R
 Recall	 Pre Ch	 [i+] / [≡i]	 Info
 Source	 AV	 Text / [≡] / [≡]	 Text
 Menu/DVD	 Menu	 Pause	 Pause
 Guide	 Guide	 Play	 Play
 [] []	 3D	 Dual	 Dual
































































































Original		Replacement		Original		Replacement	
	◀ / [≡○]		<<				
	◀ / [≡○]		Options				
	▶▶ / Subtitle		Subt				
	▶▶ / Subtitle		>>				
	▲		Smart				
	■ / [≡□]		Stop				
	⏏ / [≡⇕]		Eject				
	⏮ / [≡⇕]		I<<				
	⏭ / [⊖][≡X]		>>I				
	⏭ / [⊖][≡X]		Back				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				























































































Original	Replacement	Original	Replacement
 Power	 Power	 Right	 Right
 Mute	 Mute	 Down	 Down
 1	 1	 Vol+	 Vol +
 2	 2	 Vol-	 Vol -
 3	 3	  / [v]	 Pause
 4	 4	  / I/II	 Play
 5	 5	  / I/II	 Dual
 6	 6	  / [≡●]	 <<<
 7	 7	  / [≡●]	 TV/R
 8	 8	  / Subtitle	 >>>
 9	 9	  / Subtitle	 Subt
 0	 0	  ▲	 Smart
  _ Menu/DVD	  Menu	  ■ / [≡□]	 Stop
  - Exit/Back	  Exit	   / [≡⇅]	 Eject
  - Up	  Up	  / [≡⇅]	 I<<<
  Left	  Left	  / [⊙][≡X]	 >>>I
  OK	  Ok	  / [⊙][≡X]	 Back





Original	Replacement	Original	Replacement
 Power	 Power	  / 	 Pause
 Mute	 Mute	  / 	 Play
 1	 1	  / 	 Dual
 2	 2	  / 	 <<<
 3	 3	  / 	 TV/R
 4	 4	  / Subtitle	 >>>
 5	 5	  / Subtitle	 Subt
 6	 6	  / 	 Smart
 7	 7	  / 	 Stop
 8	 8	  / 	 Eject
 9	 9	  / 	 l<<<
 0	 0	  /  [=X]	 Back
 Source	 AV	  /  [=X]	 >>>l
 P+	 CH +		
 P-	 CH -		
 Vol-	 VOL -		
 Vol+	 VOL +		

