



	Original	Replacement		Original	Replacement
	Power		Power		Aspect
	Auto		Smart		Audio
	Mute		Mute		Display
	1		1		CH+
	2		2		CH-
	3		3		Menu
	4		4		Exit
	5		5		Up
	6		6		Down
	7		7		Right
	8		8		Left
	9		9		Ok
	0		0		Source
	-/--		Shift + Guide		P.Mode
	Recall		Back		S.Mode
	Vol+		Vol +		Sleep
	Vol-		Vol -		FAV
					3D
					Dual
					Info
					Ch +
					Ch -
					Menu
					Exit
					Up
					Down
					Right
					Left
					Ok
					AV
					Shift + Format
					Shift + Dual
					Sleep
					Pre Ch



