






















































Original	Replacement
 Power	 Power
 Info	 Info
 Mute	 Mute
 P.Mode	 Shift + Format
 S.Mode	 Shift + Dual
 Nicam	 Dual
 Aspect	 Format
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Replacement
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 EPG	 Guide
 Recall	 Back
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Source	 AV
 Sleep	 Sleep





Original	Replacement	Original	Replacement
	 Exit		 >>
	 Menu		 <<
	 Smart		 >>
	 Eject		
	 Media		
	 Subt		
	 Text		
	 +  Shift + Stop		
	 TV/R		
	 Pre Ch		
	 +  Shift + Text		
	 Rec		
	 Play		
	 Pause		
	 Stop		
	 Options		
	 I<<		

