







































































| Original  | Replacement | Original  | Replacement           |
|---|-------------|---|-----------------------|
|      | Power       |      | Power                 |
|      | Mute        |      | Mute / Dimmer         |
|      | 1           |      | 1                     |
|      | 2           |      | 2                     |
|      | 3           |      | 3                     |
|      | 4           |      | 4                     |
|      | 5           |      | 5                     |
|      | 6           |      | 6                     |
|      | 7           |      | 7                     |
|     | 8           |     | 8                     |
|    | 9           |    | 9                     |
|    | DTV/ATV     |    | Info / Angle          |
|    | 0           |    | 0                     |
|    | Recall      |    | Back / Return         |
|    | P.Mode      |    | Picture / Format      |
|    | S.Mode      |    | Sound / Title         |
|    | Sleep       |    | Sleep / Timer         |
|    | Vol+        |    | Vol+                  |
|    | MTS         |    | Setup / OPT /         |
|    | CH+         |    | CH+ / Page+           |
|    | Vol-        |    | Vol-                  |
|    | RecList     |    | Smart / List          |
|    | CH-         |    | CH- / Page-           |
|    | FAV/List    |    | Fav / Marker / PC     |
|    | Rec         |    | Rec / Rec Mode        |
|    | Freeze      |    | Pause / Step / Freeze |
|   | Menu        |   | Menu / Home           |
|  | Up          |  | Up                    |
|  | Source      |  | AV / Input / RDS      |
|  | Left        |  | Left                  |
|  | Enter       |  | OK                    |
|  | Right       |  | Right                 |
|  | Exit        |  | Exit / Cancel / Clear |
|  | Down        |  | Down                  |





| Original                  | Replacement                   |
|---------------------------|-------------------------------|
| DISPLAY                   | Display / Media               |
| Red                       | Red / Netflix / Search        |
| Green                     | Green / APP / Repeat          |
| Yellow                    | Yellow / YouTube / Repeat     |
| Blue                      | Blue / Prime Video / Random   |
| GUIDE <<                  | << / Tune-                    |
| GUIDE <<                  | Guide / EPG / -/--            |
| TIMESHIFT Play            | Play / Slow                   |
| TIMESHIFT Pause/TimeShift | Shift + Pause / Step / Step / |
| ASPECT >>                 | >> / Tune+                    |
| CANCEL I<</Cancel         | Shift + Exit / Cancel / Clear |
| CANCEL I<</Cancel         | I<< / Preset-                 |
| SUB.PG >>                 | >>I / Preset+                 |
| INDEX Stop/Index          | Stop / Hold                   |
| TVRADIO Tv/Radio          | TV/Radio /                    |
| SUBTITLE Subtitle         | Subtitle / EQ                 |
| REVEAL Reveal             | D.Menu / Top                  |

| Original | Replacement    |
|----------|----------------|
| SIZE     | Zoom / Size    |
| HOLD     | Shift + Stop / |
| TEXT     | Text / Goto    |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |
|          |                |

