


























































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	Back		Back
	EPG		Guide
	Lang		Dual
	Info		Info
	Repeat		Shift + Text
	TTX		Text
	S-T		Subt
	Menu		Menu
	Exit		Exit
	Up / CH+		Up
	Up / CH+		Ch +
	Down / CH-		Down
	Down / CH-		Ch -
	Right / Vol+		Right
	Right / Vol+		Vol +
	Left / Vol-		Left
	Left / Vol-		Vol -
	OK		Ok
	FAV		Pre Ch
	TV/R		TV/R
	List		List
	Goto		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0





	Original	Replacement	Original	Replacement
	FRW		<<	
	FFW		>>	
	Prev		I<<	
	Next		>>I	
	Play		Play	
	Pause		Pause	
	Stop		Stop	
	Rec		Rec	
	Red / OPT		Red	
	Green / RES		Green	
	Yellow / ASP		Yellow	
	Blue / Timer		Blue	
	Blue / Timer		AV	

