



Original		Replacement	
	Power		Power
	Mute		Mute
	VIDEO	 + 	Shift + 1
	S-VHS	 + 	Shift + 2
	DVD	 + 	Shift + 3
	TV	 + 	Shift + 4
	RGB	 + 	Shift + 5
	DVI	 + 	Shift + 6
	COMP	 + 	Shift + 7
	DTV (TV2)	 + 	Shift + 8
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7

Original		Replacement	
	8		8
	9		9
	0		0
	PRE		Pre Ch
	ENT		Ok
	Normal		Play
	PIP		Pause
	Split		Stop
	TV Scan		Rec
	Light		TV/R
	Picture		Format
	Sound		Dual
	Scale		3D
	On Screen		Info
	Freeze	 + 	Shift + Pause
	Up / CH+		Up
	Up / CH+		Ch +





Original	Replacement
Down / CH-	Down
Down / CH-	Ch -
Right / Vol+	Right
Right / Vol+	Vol +
Left / Vol-	Left
Left / Vol-	Vol -
Menu	Menu
Exit	Exit
Caption / Teletext	Text
Channel Mem /	Shift + Left
Channel Tune /	Shift + Up
Channel Swap /	Shift + Right
Channel CATV / Index	Shift + Down
Zoom On / Reveal	Eject
Zoom In / List/Flof	>>
Zoom out /	<<
Auto / Cancel	Back

Original	Replacement
Red / Sound Surround	Red
Green / Sound Stereo	Green
Yellow / Sound Bilingual	Yellow
Yellow / Sound Bilingual	Shift + Dual
Blue / EPG	Blue
Blue / EPG	Guide
Sleep	Sleep
Wake Up	D. Menu
Set Up	Options
PIP CH+	>>
PIP CH-	<<
PIP Switch Audio	Smart
PIP Switch Video	Media
PIP Source	AV
PIP Size	Subt
PIP Position	List

