








































































































Original	Replacement	Original	Replacement
 Power	 Power	 Menu	 Menu
 Source	 AV	 Ch +	 Ch +
 Mute	 Mute	 Ch -	 Ch -
 1	 1	 Play	 Play
 2	 2	 Pause	 Pause
 3	 3	 Stop	 Stop
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Right	 Right
 7	 7	 Left	 Left
 8	 8	 Ok	 Ok
 9	 9	 Red/Image	 Red
 0	 0	 Green/Audio	 Green
 -/--	 Guide	 Yellow/Sleep	 Yellow
 Recall	 Back	 Blue/Freeze	 Blue
 Vol +	 Vol +	 ←	 Media
 Vol -	 Vol -	 →	 Smart

Original	Replacement	Original	Replacement
 Menu	 Menu	 Ch +	 Ch +
 Ch -	 Ch -	 Play	 Play
 Pause	 Pause	 Stop	 Stop
 Up	 Up	 Down	 Down
 Right	 Right	 Left	 Left
 Ok	 Ok	 Red/Image	 Red
 Green/Audio	 Green	 Yellow/Sleep	 Yellow
 Blue/Freeze	 Blue	 ←	 Media
 →	 Smart		



