

















Original		Replacement		Original		Replacement	
	Power		Power				
	Start/Stop		Play				
	Speed+		Up				
	Speed-		Down				
	Time-		Left				
	Time+		Right				
	Program		Smart				
	Manual		Media				

