















































































































Original	Replacement	Original	Replacement
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
App	 Media	Menu Down	 Down
Opt?	 Options	Audio	 Dual
TV	 TV/R	Back	 Back
Info	 +  Shift + Info	Volume+	 Vol +
Subt.List	 Subt	CH/Page+	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7



Original	Replacement	Original	Replacement
8tuv	 8	+	 +  Shift + Subt
9wxyz	 9	Auth./DISEQC	 +  Shift + Smart
Guide Pilote	 Guide	Sys/Serv	 +  Shift + Sleep
0/10	 0	Home Cinema	 Smart
FAV Pref.	 Pre Ch	Scan/Setup	 +  Shift + Options
Red	 Red	Interat	 +  Shift + D. Menu
Green	 Green	Pers.	 +  Shift + Eject
Yellow	 Yellow	Tune-	 +  Shift + Left
Freeze	 Stop	East	 >>I
Blue	 Blue	H/V Play	 Play
Dev	 List	LNB F.Forward	 >>
22Khz	 3D	Lang./Rewind	 <<
West	 I<<	Alt/16:9	 Format
Radio	 +  Shift + TV/R	Aft/Caf	 +  Shift + Ok
On/Off	 +  Shift + Power	Tune+	 +  Shift + Right
Dec/Pause	 Pause		 +  Shift + Exit
	 +  Shift + Mute	Browse	 +  Shift + Back








































Original	Replacement	Original	Replacement
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
Subt.List	 Subt	Menu Down	 Down
Opt?	 Options	Back	 Back
App	 Media	Audio	 Dual
Info	 +  Shift + Info	Volume+	 Vol +
Sleep Timer	 Sleep	CH/Page+	 Ch +
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7













Original	Replacement	Original	Replacement
8tuv	 8	SAT Sky	 +  Shift + AV
9wxyz	 9	Navi Mode	 +  Shift + Menu
Guide Pilote	 Guide	Browse	 +  Shift + Media
0/10	 0	Search	 +  Shift + Up
FAV Pref.	 Pre Ch	Auth./DISEQC	 3D
Red	 Red	Tune-	 +  Shift + Left
Green	 Green	Tune+	 +  Shift + Right
Yellow	 Yellow	East	 >>
Blue	 Blue		 +  Shift + Exit
On/Off	 +  Shift + Power	Lang./Rewind	 <<
Scan/Setup	 +  Shift + Options	H/V Play	 Play
Radio	 +  Shift + TV/R	Store	 +  Shift + Down
	 +  Shift + Mute	Alt/16:9	 Format
22Khz	 List		 +  Shift + Vol +
+	 +  Shift + Subt	Home Cinema	 Smart
Sys/Serv	 +  Shift + Sleep		 +  Shift + Vol -
Pers.	 +  Shift + Eject		







































Original	Replacement	Original	Replacement
PWR On/Off	 Power	Exit	 Exit
Mute	 Mute	Menu Down	 Down
Opt?	 Options	Back	 Back
Info	 +  Shift + Info	Volume+	 Vol +
Subt.List	 Subt	CH/Page+	 Ch +
Sleep Timer	 Sleep	Audio	 Dual
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7
OK Enter	 Ok	8tuv	 8
Menu Right	 Right	9wxyz	 9



Original	Replacement	Original	Replacement
Guide Pilote	 Guide		
0/10	 0		
FAV Pref.	 Pre Ch		
Red	 Red		
Green	 Green		
Dec/Pause	 Pause		
Lang./Rewind	 <<		
Freeze	 Stop		
LNB F.Forward	 >>		
H/V Play	 Play		
East	 >>		
Yellow	 Yellow		
Blue	 Blue		



Original	Replacement	Original	Replacement
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
Subt.List	 Subt	Menu Down	 Down
Opt?	 Options	Back	 Back
App	 Media	Audio	 Dual
Info	 +  Shift + Info	Volume+	 Vol +
Sleep Timer	 Sleep	CH/Page+	 Ch +
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7





Original	Replacement	
8tuv	 8	
9wxyz	 9	
Guide Pilote	 Guide	
0/10	 0	
FAV Pref.	 Pre Ch	
Red	 Red	
Green	 Green	
Yellow	 Yellow	
Blue	 Blue	
On/Off	 +  Shift + Power	
Scan/Setup	 +  Shift + Options	
	 +  Shift + Mute	
Dec/Pause	 Pause	
+	 +  Shift + Subt	
Sys/Serv	 +  Shift + Sleep	
Interat	 +  Shift + D. Menu	
SAT Sky	 +  Shift + AV	

Original	Replacement	
22Khz	 List	
Radio	 +  Shift + TV/R	
Navi Mode	 +  Shift + Menu	
Search	 +  Shift + Up	
Tune-	 +  Shift + Left	
Tune+	 +  Shift + Right	
	 +  Shift + Exit	
Store	 +  Shift + Down	
	 +  Shift + Vol +	
	 +  Shift + Ch +	
	 +  Shift + Vol -	
Home Cinema	 Smart	
	 +  Shift + Ch -	
De-emph	 +  Shift + 1	
Swap	 +  Shift + 2	
P.lock	 +  Shift + 3	
Wn	 +  Shift + 4	



