































































Original	Replacement	
On/Off		Power
Audio Off		Mute
Slow Down		Ch -
Slow Up		Ch +
Pause		Pause
Auto/Track		Smart
Stop		Stop
Subt.		Subt
Title		List
Rep/A-B		TV/R
Pepeat/1/All		Text
Zoom		Shift + Eject
DVD/TV		AV
Menu		Menu
Menu Up		Up
Display		Info
Return		Back

Original	Replacement	
Menu Left		Left
OK Enter		Ok
Progr.		Sleep
Next		>>
Menu Right		Right
Prev.		<<
Menu Down		Down
Volume+		Vol +
Volume-		Vol -
Top Menu		D. Menu
1		1
2		2
3		3
4		4
5		5
Store		Red
6		6















Original	Replacement	Original	Replacement
Digest	Green	Angle	Format
7	7	Np	Shift + Subt
Open/Close	Eject	Info	Shift + Info
8	8		
9	9		
Clear/00:00	Exit		
+10	Guide		
Record	Rec		
Auto Scan	Media		
Rewind	<<		
Play	Play		
F.Forward	>>		
Setup	Options		
Audio	Dual		
3D	3D		
0	0		
C/CH	Pre Ch		





































Original	Replacement	Original	Replacement
On/Off	 Power	OK Enter	 Ok
Audio Off	 Mute	Menu Right	 Right
Stop	 Stop	Return	 Exit
Pause	 Pause	Menu Down	 Down
Slow Up	 Ch +	Progr.	 Back
Slow Down	 Ch -	Volume+	 Vol +
Subt.	 Subt	Top Menu	 D. Menu
Auto/Track	 Sleep	Next	 >>
Rep/A-B	 TV/R	Volume-	 Vol -
Zoom	 Shift + Eject	1	 1
Title	 List	2	 2
Pepeat/1/All	 Text	3	 3
DVD/TV	 AV	Prev.	 <<
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Info	6	 6
Menu Left	 Left	7	 7







Original	Replacement	Original	Replacement
8		8	
Video			
9		9	
+10			
0		0	
C/CH			
Rewind		<<	
Random			
Angle			
R/L	 + 	Shift + Info	
Play		Play	
Record		Rec	
F.Forward		>>	
3D		3D	
Open/Close		Eject	
Audio		Dual	



Original	Replacement	Original	Replacement
On/Off	 Power	OK Enter	 Ok
Audio Off	 Mute	Menu Right	 Right
Slow Down	 Ch -	Return	 Back
Slow Up	 Ch +	Menu Down	 Down
Auto/Track	 Smart	Next	 >>
Stop	 Stop	Progr.	 Sleep
Subt.	 Subt	Volume+	 Vol +
Pause	 Pause	Top Menu	 D. Menu
Zoom	 Shift + Eject	Volume-	 Vol -
Title	 List	Prev.	 <<
Rep/A-B	 TV/R	1	 1
Pepeat/1/All	 Text	2	 2
DVD/TV	 AV	3	 3
Menu	 Menu	4	 4
Menu Up	 Up	5	 5
Display	 Info	6	 6
Menu Left	 Left	7	 7



Original	Replacement	
8		8
Open/Close		Eject
Mode		Media
9		9
Setup		Options
+10		Guide
3D		3D
0		0
C/CH		Pre Ch
Play/Back	 + 	Shift + Left
Resume	 + 	Shift + Play
Play		Play
Karaoke/Step	 + 	Shift + Pause
Np	 + 	Shift + Subt
Record		Rec
F.Forward		>>
Rewind		<<

Original	Replacement	
Store	 + 	Shift + Down
Angle		Format
Lang		Dual

