





































































Original	Replacement	Original	Replacement
 Power	 Power	 Green	 Green
 Mute	 Mute	 Yellow	 Yellow
 TV/AV	 AV	 Blue	 Blue
 TXT/TV	 Text	 Stop	 Pause
 1	 1	 Cancel	 Exit
 2	 2	 Size	 Eject
 3	 3	 Recall/Reveal	 Back
 4	 4	 F	 Ok
 5	 5	 Up	 Up
 6	 6	 P+	 Ch +
 7	 7	 Down	 Down
 8	 8	 P-	 Ch -
 9	 9	 Right	 Right
 0	 0	 Vol+	 Vol +
 P-P / List	 Pre Ch	 Left	 Left
 -/-	 Guide	 Vol-	 Vol -
 Red	 Red	 Menu/Index	 Menu



