





































































Original	Replacement	Original	Replacement
	Power		Power
	i		Info
	Input Select		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Sleep		Sleep
	Mode		Smart
	Menu		Menu
	Sound Select		Dual
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Back		Back
	Guide		Guide
	Vol +		Vol +
	Vol -		Vol -
	Mute		Mute
	P +		Ch +
	P -		Ch -
	DTV / Radio		TV/R
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue





Original	Replacement	Original	Replacement
Color System	Options		
Reveal	Media		
Expand	3D		
Sub Code	Shift + Subt		
[≡]	Text		
[...]	Subt		
[≡i]	Shift + Info		
[≡□]	Stop		

