



| Original | Replacement | | |
|----------|--------------|---|-----------------------------|
| | Power | | Power |
| | Info | | Info / Angle |
| | Sleep | | Sleep / Timer |
| | Tv/R | | TV/Radio / |
| | AUX | + | Shift + 7 |
| | EPG | | Guide / EPG / -/-- |
| | Audio | | Audio / Lang I/II |
| | Red/Text | + | Shift + Red / Netflix / |
| | Green/Recall | + | Shift + Green / APP / |
| | Yellow/Games | + | Shift + Yellow / YouTube / |
| | Blue/Audio | | Blue / Prime Video / Random |
| | Exit | | Exit / Cancel / Clear |
| | Menu | | Menu / Home |
| | FAV >> | | >> / Tune+ |
| | << FAV | | << / Tune- |
| | Up | | Up |
| | OK | | OK |

| Original | Replacement | | |
|----------|-------------|--|-----------------------|
| | Down | | Down |
| | Right | | Right |
| | Vol+ | | Vol+ |
| | Vol- | | Vol- |
| | Left | | Left |
| | Pause | | Pause / Step / Freeze |
| | Mute | | Mute / Dimmer |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 0 | | 0 |



