





| Original | Replacement |
|---|-------------|
|  | Power |
|  | Sleep |
|  | Open/Close |
|  | Intro |
|  | Source |
|  | Info |
|  | I<< |
|  | Menu / Rep |
|  | Menu / Rep |
|  | EQ |
|  | << |
|  | Play |
|  | Pause |
|  | >> |
|  | >>I |
|  | 10-/Tun- |
|  | 10-/Tun- |

Tune-

| Original | Replacement |
|---|-------------|
|  | 10+/Tun+ |
|  | 10+/Tun+ |
|  | Stop / Auto |
|  | Stop / Auto |
|  | Fold- |
|  | Fold+ |
|  | Prog/Memory |
|  | Vol- |
|  | Vol+ |
|  | Clock |
|  | Mute/Alarm |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

