








































































Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 TV/Radio	 TV/Radio /
 0	 0
 Fav	 Fav / Marker / PC
 Vol+	 Vol+
 Reclist	 Setup / OPT /
 Reclist	 Shift + Smart / List

Original	Replacement
 CH+	 CH+ / Page+
 Vol-	 Vol-
 Guide	 Guide / EPG / -/--
 CH-	 CH- / Page-
 Rec	 Rec / Rec Mode
 MTS	 Smart / List
 Aspect	 Picture / Format
 Menu	 Menu / Home
 Up	 Up
 Source	 AV / Input / RDS
 Left	 Left
 Enter	 OK
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Display	 Display / Media
 Red	 Red / Netflix / Search





Original	Replacement	Original	Replacement
 Green	 Green / APP / Repeat		
 Yellow	 Yellow / YouTube / Repeat		
 Cyan	 Blue / Prime Video / Random		
 << / Index	 << / Tune-		
 >> / TTX	 Text / Goto		
 >> / TTX	 >> / Tune+		
 I<< / Sub.Pg	 I<< / Preset-		
 >>I / Reveal	 >>I / Preset+		
 Stop / Hold	 Stop / Hold		
 Play/Pause /	 Shift + Exit / Cancel / Clear		
 Play/Pause /	 Play / Slow		
 Size	 Zoom / Size		
 Subtitle	 Subtitle / EQ		

