






































































Original	Replacement	Original	Replacement
	Power		MTS
	Mute		Menu
	1		Up
	2		Source
	3		Left
	4		Enter
	5		Right
	6		Exit
	7		Down
	8		Display
	9		Vol+
	0		Rec
	ATV/DTV		Rec List
	Recall		CH+
	P.Mode		Vol-
	S.Mode		Tv/Radio
	Sleep		FAV List
	Power		D.Menu / Top
	Mute / Dimmer		Menu / Home
	1		Up
	2		AV / Input / RDS
	3		Left
	4		OK
	5		Right
	6		Exit / Cancel / Clear
	7		Down
	8		Display / Media
	9		Vol+
	0		Rec / Rec Mode
	Guide / EPG / -/--		Shift + Rec / Rec Mode
	Back / Return		CH+ / Page+
	Picture / Format		Vol-
	Sound / Title		TV/Radio /
	Sleep / Timer		Smart / List





Original	Replacement
 CH-	 CH- / Page-
 Play/Time Shift	 Play / Slow
 Pause	 Pause / Step / Freeze
 <</Guide	 << / Tune-
 >>/Aspect	 >> / Tune+
 Freeze	 Shift + Pause / Step /
 Stop/Index	 Stop / Hold
 <</Cancel	 << / Preset-
 >> /Sub.PG	 >> / Preset+
 Subtitle	 Subtitle / EQ
 Reveal	 Setup / OPT /
 Size	 Zoom / Size
 Hold	 Shift + Stop /
 Text	 Text / Goto
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat

Original	Replacement
 Cyan	 Blue / Prime Video / Random

