


































































































| Original | Replacement |
|--|---|
|  Open/Close |  Eject / Surround |
|  V.Mode |  Picture / Format |
|  Power |  Power |
|  OSD |  Display / Media |
|  Subtitle |  Subtitle / EQ |
|  Title |  Sound / Title |
|  Menu |  Menu / Home |
|  Repeat |  Green / APP / Repeat |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  A-B RPT |  Yellow / YouTube / Repeat |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  Prog |  TV/Radio / |
|  7 |  7 |

| Original | Replacement |
|--|--|
|  8 |  8 |
|  9 |  9 |
|  Intro |  AV / Input / RDS |
|  Search |  Red / Netflix / Search |
|  0 |  0 |
|  10+ |  Guide / EPG / -/- |
|  Setup |  Setup / OPT / |
|  Pause |  Pause / Step / Freeze |
|  Up |  Up |
|  Left |  Left |
|  Enter/Play |  OK |
|  Right |  Right |
|  Return |  Back / Return |
|  Down |  Down |
|  Stop |  Stop / Hold |
|  <</F.REV |  << / Tune- |
|  >>/F.FWD |  >> / Tune+ |





| | Original | Replacement | | Original | Replacement |
|--|---|-------------|--|---|--------------------------|
| |  | I<</Prev | |  | I<< / Preset- |
| |  | >>I/Next | |  | >>I / Preset+ |
| |  | <I Slow | |  | CH- / Page- |
| |  | Slow I> | |  | CH+ / Page+ |
| |  | Step | |  | Shift + Pause / Step / |
| |  | Zoom | |  | Zoom / Size |
| |  | Angle | |  | Info / Angle |
| |  | PBC | |  | Text / Goto |
| |  | Volume- | |  | Vol- |
| |  | Volume+ | |  | Vol+ |
| |  | Mute | |  | Mute / Dimmer |
| |  | NTSC/PAL | |  | Shift + Picture / Format |
| |  | Track | |  | D.Menu / Top |
| |  | Audio | |  | Audio / Lang I/II |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| | Original | Replacement |
|--|----------|-------------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

