





































Original	Replacement
 Power	 Power
 Play	 Play / Slow
 Still/Pause	 Pause / Step / Freeze
 Stop/Live	 Stop / Hold
 Rec	 Rec / Rec Mode
 <</REV	 << / Tune-
 >>/FWD	 >> / Tune+
 I<< Skip/<I	 I<< / Preset-
 F.ADV II>/Skip	 >>I / Preset+
 DVD Title/Rec List	 Sound / Title
 Audio	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 Open/Close	 Eject / Surround
 Zoom/Mode Rec	 Zoom / Size
 AV Auto Rec	 TV/Radio /
 Direct	 D.Menu / Top
 C/Erase	 Setup / OPT /

Original	Replacement
 Timeshift	 Text / Goto
 Input	 AV / Input / RDS
 DVD Menu/Original	 Menu / Home
 Up	 Up
 CH Display	 Info / Angle
 Left	 Left
 Set/Enter	 OK
 Right	 Right
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Return	 Back / Return
 Vol+ Tv	 Vol+
 Start Menu	 Smart / List
 CH+	 CH+ / Page+
 Vol- Tv	 Vol-
 Display/Back	 Display / Media
 CH-	 CH- / Page-





Original	Replacement
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
100/ENT./AM/F	Guide / EPG / -/--
0	0
VCR Plus	Fav / Marker / PC
Red/B	Red / Netflix / Search
Green/C	Green / APP / Repeat
Yellow/D	Yellow / YouTube / Repeat
Blue/A	Blue / Prime Video / Random
Power Tv	Shift + Power

Original	Replacement
Replay	Shift + Play /
Rec Pause	Shift + Pause / Step /
Rec Stop	Shift + Stop /
Skip Search	Shift + << /
I> Slow	Shift + >>I / Preset+
	Shift + Zoom /
	Shift + D.Menu / Top Menu
Dubbing	Shift + Setup / OPT / Tools
P.IN P	Shift + Text /
Input Tv	Shift + AV / Input / RDS
	Shift + Info / Angle
	Shift + Smart / List
	Shift + CH+ /
	Shift + CH- /
DVD	Shift + 2
HDD	Shift + 7

