




































































Original	Replacement
	 Power
	 AV / Input / RDS
	 Shift + 1
	 Shift + Yellow / YouTube /
	 Shift + Blue / Prime
	 Shift + 4
	 Shift + 5
	 Shift + 6
	 Shift + 7
	 Shift + 8
	 Shift + 9
	 Shift + Red / Netflix /
	 Shift + 0
	 Fav / Marker / PC
	 Red / Netflix / Search
	 Green / APP / Repeat
	 Yellow / YouTube / Repeat

Original	Replacement
	 Blue / Prime Video / Random
	 D.Menu / Top
	 Up
	 Play / Slow
	 Pause / Step / Freeze
	 Left
	 OK
	 Right
	 Back / Return
	 Down
	 Exit / Cancel / Clear
	 Vol+
	 Menu / Home
	 CH+ / Page+
	 Vol-
	 Display / Media
	 CH- / Page-





Original	Replacement	Original	Replacement
 Subtitle	 Subtitle / EQ		
 Mute	 Mute / Dimmer		
 Text	 Text / Goto		
 1	 1		
 2	 2		
 3	 3		
 4	 4		
 5	 5		
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 Guide	 Guide / EPG / -/--		
 0	 0		
 CH.List	 Smart / List		

Original	Replacement	Original	Replacement

