



Original	Replacement	Original	Replacement
 Power	 Power	 0/10	 0
 Open / Close	 Eject / Surround	 10+	 Guide / EPG / -/-
 Language	 Audio / Lang I/II	 Prog	 TV/Radio /
 Angle	 Info / Angle	 Mute	 Mute / Dimmer
 Subtitle	 Subtitle / EQ	 Zoom	 Zoom / Size
 Time	 Sleep / Timer	 A-B	 Yellow / YouTube / Repeat
 Display	 Display / Media	 Repeat	 Green / APP / Repeat
 PDVD	 Smart / List	 Step	 Shift + Pause / Step /
 1	 1	 Slow	 Shift + Play /
 2	 2	 Return	 Back / Return
 3	 3	 Resume	 Fav / Marker / PC
 4	 4	 View	 AV / Input / RDS
 5	 5	 Ran	 Blue / Prime Video / Random
 6	 6	 Vol-	 Vol-
 7	 7	 Vol+	 Vol+
 8	 8	 Menu	 Menu / Home
 9	 9	 Up	 Up



