






































































































Original	Replacement	Original	Replacement
 Power	 Power	 6	 6
 Tv/TXT	 Text	 7	 7
 Input	 AV	 8	 8
 OK	 Ok	 9	 9
 Up	 Up	 0	 0
 Down	 Down	 Back	 Back
 Right	 Right	 FAV	 Shift + Pre Ch
 Left	 Left	 Menu	 Menu
 Vol+	 Vol +	 Exit	 Exit
 Vol-	 Vol -	 Nicam/A2	 Shift + Guide
 CH+	 Ch +	 Display	 Shift + Info
 CH-	 Ch -	 Mute	 Mute
 1	 1	 Picture	 Format
 2	 2	 Sound	 Dual
 3	 3	 Sleep	 Sleep
 4	 4	 Subtitle	 Subt
 5	 5	 EPG	 Guide





Original	Replacement	Original	Replacement
 CH/List	 Pre Ch		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue/Screen	 Blue		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		
 Record	 Rec		
 >>/Size	 >>		
 <</Hold	 <<		
 Cancel	 Shift + Back		
 Reveal/Rep	 Eject		
 <</Subpage	 D. Menu		
 >> /Index	 Info		
 List	 List		

