





















































Original	Replacement
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Mute	 Mute
 16:9	 Format
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue

Original	Replacement
 TV	 TV/R
 AV	 AV
 Up / P+	 Up
 Up / P+	 Ch +
 Down / P-	 Down
 Down / P-	 Ch -
 Right / V+	 Right
 Right / V+	 Vol +
 Left / V-	 Left
 Left / V-	 Vol -
 Menu	 Menu
 Menu	 Ok
 S / M / D	 Smart
 Recall	 Pre Ch
 Recall	 Back
 ≡	 Text
 ≡	 Options





Original		Replacement	
	≡o		Sleep
	≡i		Info
	Hold		Pause
	Size		Eject
	≡X		Exit
	≡?		D. Menu
	PP		Media
	i		Shift + Info

Original		Replacement	

