



































| Original | Replacement | Original | Replacement |
|-------------|---|------------|---|
| On/Off |  Power | Menu Right |  Right |
| Mute |  Mute | Menu Down |  Down |
| Update |  List | Back |  Back |
| Txt Stop |  Stop | Volume+ |  Vol + |
| Reveal |  Smart | Chan.Up |  Ch + |
| Subt.List |  Subt | Volume- |  Vol - |
| Sleep Timer |  Sleep | Menu audio |  Dual |
| Info |  Info | Chan.Down |  Ch - |
| Return TV |  TV/R | 1 |  1 |
| Menu video |  D. Menu | 2 |  2 |
| Text |  Text | 3 |  3 |
| TV/AV |  AV | 4 |  4 |
| Menu |  Menu | 5 |  5 |
| Menu Up |  Up | 6 |  6 |
| Display |  Shift + Info | 7 |  7 |
| Menu Left |  Left | 8 |  8 |
| OK Enter |  Ok | 9 |  9 |



