



















































Original	Replacement	Original	Replacement
 Keystone+	 Up	 7/Freeze	 Pause
 Keystone-	 Down	 8/Aspect Ratio	 Format
 Vol+	 Right	 8/Aspect Ratio	 8
 Vol+	 Vol +	 9 / Hide	 9
 Vol-	 Left	 0/e	 3D
 Vol-	 Vol -	 0/e	 0
 Menu	 Menu	 Standby	 Power
 Menu	 Ok		
 1/VGA	 1		
 2/Video	 2		
 3/S-Video	 3		
 4/Re-Sync	 4		
 5/Zoom	 Eject		
 5/Zoom	 5		
 6/Source	 6		
 6/Source	 AV		
 7/Freeze	 7		

