


Original	Replacement
	Power
	Mute
	Eject
	Pre Ch
	Vol +
	Vol -
	Info
	Smart
	Ch +
	Ch -
	Menu
	Exit
	Up
	Down
	Right
	Left
	Ok

Original	Replacement
	Red
	Green
	Yellow
	Blue
	Subt
	Text
	Options
	TV/R
	Back
	1
	2
	3
	4
	5
	6
	7
	8





Original		Replacement		Original		Replacement	
	9		9				
	0		0				
	Audio		Dual				
	EPG		Guide				
	<<		<<				
	Play		Play				
	>>		>>				
	Stop		Stop				
	Pause		Pause				
	I<<		I<<				
	>>I		>>I				
	Rec		Rec				
	Rec List		List				

