







































































Original		Replacement		Original		Replacement	
	Power		Power		Rec		Rec
	Input		AV		CH+		Ch +
	Mute		Mute		CH-		Ch -
	1		1		Vol+		Vol +
	2		2		Vol-		Vol -
	3		3		FAV		Pre Ch
	4		4		OK		Ok
	5		5		Up		Up
	6		6		Down		Down
	7		7		Right		Right
	8		8		Left		Left
	9		9		EPG		Guide
	0		0		Info		Info
	Return		Back		Goto/PlayList		Options
	Menu		Menu		ECO/TFT Off		Media
	Exit		Exit		Play		Play
	[:=]		Smart		Pause/TS		Pause





Original	Replacement	Original	Replacement
 Stop/Reveal	 Stop		
 Repeat/TV/TXT	 Text		
 I<</Hold	 I<<		
 >>I/Subpage	 >>I		
 <</Index	 <<		
 >>/Cancel	 >>		
 Red	 Red		
 Subtitle	 Subt		
 Green	 Green		
 Audio	 Dual		
 Yellow	 Yellow		
 16:9	 Format		
 Blue	 Blue		
 Sleep	 Sleep		

