



































































































Original	Replacement	Original	Replacement
 Standby	 Power	 Aspect	 Format
 Mute	 Mute	 Info. / Display	 Info
 1	 1	 CH+	 Ch +
 2	 2	 CH-	 Ch -
 3	 3	 Up	 Up
 4	 4	 Left	 Left
 5	 5	 OK	 Ok
 6	 6	 Right	 Right
 7	 7	 Down	 Down
 8	 8	 Menu	 Menu
 9	 9	 Source	 AV
 0	 0	 Exit	 Exit
 -/--	 Shift + Guide	 Freeze	 Pause
 Recall	 Back	 P.Mode	 Shift + Format
 Vol+	 Vol +	 S.Mode	 Shift + Dual
 Vol-	 Vol -	 FAV	 Pre Ch
 Sleep	 Sleep	 EPG	 Guide





Original	Replacement	Original	Replacement
 Subtitle	 Subt		
 TV / Radio	 TV/R		
 Audio I / II	 Dual		
 Text	 Text		
 Index	 Smart		
 Mix	 Shift + Text		
 Reveal	 Media		
 Size	 Eject		
 Subpage	 Shift + Subt		
 Hold	 Stop		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

