



Original	Replacement	Original	Replacement
Power	Power	Vol-	Vol - / Page -
Auto Set	Auto	Freeze	Freeze / Timer
Aspect	Eco / Aspect	Blank	Blank / Mute
Input	Source	Mute	Shift + Blank / Mute
Auto PC	Shift + Auto	Image	Mode
Focus	Volt / Focus	P-Timer	Shift + Freeze / Timer
Zoom	Shift + + / Play	Lamp	Comp / Video
Up/1	Up		
Left/4	Left		
OK	Enter		
Right/2	Right		
Down/3	Down		
Keystone/D.Shift	3D / Invert		
Menu	Menu		
D.Zoom+	+ / Play		
D.Zoom-	- / Stop		
Vol+	Vol + / Page +		

