





























































Original		Replacement		Original		Replacement	
	Power		Power		Info		Info
	Mute		Mute		Up		Up
	1		1		Right		Right
	2		2		Down		Down
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Exit		Exit
	6		6		Menu		Menu
	7		7		EPG		Guide
	8		8		Vol +		Vol +
	9		9		Vol -		Vol -
	0		0		CH + / Page +		Ch +
	Text		Text		CH - / Page -		Ch -
	Audio		Dual		Red		Red
	Help		D. Menu		Green		Green
	Back		Back		Yellow		Yellow
	Subtitle		Subt		Blue		Blue





Original	Replacement	Original	Replacement
 Rec	 Rec		
 Stop	 Stop		
 Play / Pause	 Play		
 Play / Pause	 Pause		
 Timer	 AV		
 I<	 I<<		
 <<	 <<		
 >>	 >>		
 >	 >>		
 V.Mode	 Format		
 TV	 TV/R		
 Radio	 Shift + TV/R		
 Sleep	 Sleep		

