







































































Original	Replacement	Original	Replacement
 Standby	 Power	 Up / Channel+	 Ch +
 1	 1	 Down /	 Down
 2	 2	 Down /	 Ch -
 3	 3	 Right	 Right
 4	 4	 Left	 Left
 5	 5	 Select	 Ok
 6	 6	 Mute	 Mute
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 Menu	 Menu
 0	 0	 A/V	 AV
 SAT / Recall	 Smart	 Tune	 Media
 SAT / Recall	 Back	 Text	 Text
 Favorite	 Pre Ch	 Subtitle	 Subt
 View	 Info	 Store	 Options
 Cancel	 Exit	 Reveal	 3D
 Up / Channel+	 Up	 Aspect	 Format

