



































Original	Replacement
 On	 Power
 Standby	 Shift + Power
 Search	 TV/R
 Computer	 1
 BNC	 2
 DVI-D	 3
 VIDEO	 4
 S-VIDEO	 5
 HDMI	 6
 LAN	 7
 HDBaseT	 8
 SDI	 9
 Auto	 Smart
 Aspect	 Format
 Color Mode	 Options
 Test Pattern	 Play
 Freeze	 Pause

Original	Replacement
 Shutter	 Stop
 Lens Shift	 Text
 Zoom	 Eject
 Focus	 AV
 Menu	 Menu
 Esc / Mouse Right	 Exit
 Up	 Up
 Left	 Left
 Enter / Mouse Left	 Ok
 Right	 Right
 Down	 Down
 Split	 Guide
 Default	 Pre Ch
 Page Up	 Ch +
 Page Down	 Ch -
 E-Zoom+	 Vol +
 E-Zoom-	 Vol -







































Original		Replacement		Original	Replacement
User1	User1	A	Red		
User2	User2	B	Green		
User3	User3	C	Yellow		
1	1	SHIFT + 1	Shift + 1		
2	2	SHIFT + 2	Shift + 2		
3	3	SHIFT + 3	Shift + 3		
4	4	SHIFT + 4	Shift + 4		
5	5	SHIFT + 5	Shift + 5		
6	6	SHIFT + 6	Shift + 6		
7	7	SHIFT + 7	Shift + 7		
8	8	SHIFT + 8	Shift + 8		
9	9	SHIFT + 9	Shift + 9		
0	0	SHIFT + 0	Shift + 0		
Help ?	Help	E-MANUAL D.MENU	D. Menu		





Original	Replacement
 On	 Power
 Standby	 Shift + Power
 Search	 TV/R
 Computer	 1
 BNC	 2
 DVI-D	 3
 VIDEO	 4
 S-VIDEO	 5
 HDMI	 6
 LAN	 7
 HDBaseT	 8
 SDI	 9
 Auto	 Smart
 Aspect	 Format
 Color Mode	 Options
 Test Pattern	 Play
 Freeze	 Pause

Original	Replacement
 Shutter	 Stop
 Lens Shift	 Text
 Zoom	 Eject
 Focus	 AV
 Menu	 Menu
 Esc / Mouse Right	 Exit
 Up	 Up
 Left	 Left
 Enter / Mouse Left	 Ok
 Right	 Right
 Down	 Down
 Split	 Guide
 Default	 Pre Ch
 Page Up	 Ch +
 Page Down	 Ch -
 E-Zoom+	 Vol +
 E-Zoom-	 Vol -




































Original		Replacement		Original	Replacement
User1	User1	A	Red		
User2	User2	B	Green		
User3	User3	C	Yellow		
1	1	SHIFT + 1	Shift + 1		
2	2	SHIFT + 2	Shift + 2		
3	3	SHIFT + 3	Shift + 3		
4	4	SHIFT + 4	Shift + 4		
5	5	SHIFT + 5	Shift + 5		
6	6	SHIFT + 6	Shift + 6		
7	7	SHIFT + 7	Shift + 7		
8	8	SHIFT + 8	Shift + 8		
9	9	SHIFT + 9	Shift + 9		
0	0	SHIFT + 0	Shift + 0		
Help ?	Help	E-MANUAL D.MENU	D. Menu		








Original	Replacement
 On	 Power
 Standby	 Shift + Power
 Search	 TV/R
 Computer	 1
 BNC	 2
 DVI-D	 3
 VIDEO	 4
 S-VIDEO	 5
 HDMI	 6
 LAN	 7
 HDBaseT	 8
 SDI	 9
 Auto	 Smart
 Aspect	 Format
 Color Mode	 Options
 Test Pattern	 Play
 Freeze	 Pause

Original	Replacement
 Shutter	 Stop
 Lens Shift	 Text
 Zoom	 Eject
 Focus	 AV
 Menu	 Menu
 Esc / Mouse Right	 Exit
 Up	 Up
 Left	 Left
 Enter / Mouse Left	 Ok
 Right	 Right
 Down	 Down
 Split	 Guide
 Default	 Pre Ch
 Page Up	 Ch +
 Page Down	 Ch -
 E-Zoom+	 Vol +
 E-Zoom-	 Vol -
























Original		Replacement		Original		Replacement	
	User1		Red				
	User2		Green				
	User3		Yellow				
	1		Shift + 1				
	2		Shift + 2				
	3		Shift + 3				
	4		Shift + 4				
	5		Shift + 5				
	6		Shift + 6				
	7		Shift + 7				
	8		Shift + 8				
	9		Shift + 9				
	0		Shift + 0				
	Help		D. Menu				





Original	Replacement	Original	Replacement
 On	 Power	 Shutter	 Stop
 Standby	 Shift + Power	 Lens Shift	 Text
 Search	 TV/R	 Zoom	 Eject
 Computer	 1	 Focus	 AV
 BNC	 2	 Menu	 Menu
 DVI-D	 3	 Esc / Mouse Right	 Exit
 VIDEO	 4	 Up	 Up
 S-VIDEO	 5	 Left	 Left
 HDMI	 6	 Enter / Mouse Left	 Ok
 LAN	 7	 Right	 Right
 HDBaseT	 8	 Down	 Down
 SDI	 9	 Split	 Guide
 Auto	 Smart	 Default	 Pre Ch
 Aspect	 Format	 Page Up	 Ch +
 Color Mode	 Options	 Page Down	 Ch -
 Test Pattern	 Play	 E-Zoom+	 Vol +
 Freeze	 Pause	 E-Zoom-	 Vol -





Original		Replacement		Original		Replacement	
User1	User1	A	Red				
User2	User2	B	Green				
User3	User3	C	Yellow				
0	0	SHIFT + 0	Shift + 0				
1	1	SHIFT + 1	Shift + 1				
2	2	SHIFT + 2	Shift + 2				
3	3	SHIFT + 3	Shift + 3				
5	5	SHIFT + 5	Shift + 5				
6	6	SHIFT + 6	Shift + 6				
7	7	SHIFT + 7	Shift + 7				
8	8	SHIFT + 8	Shift + 8				
9	9	SHIFT + 9	Shift + 9				
4	4	SHIFT + 4	Shift + 4				
Help ?	Help	E-MANUAL D.MENU	D. Menu				

