



Original	Replacement	Original	Replacement
	Power		Blue/[ ]
	Vol +		Info
	Vol -		Text
	Ch +		1
	Ch -		2
	Mute		3
	Menu		4
	Exit		5
	Back		6
	Ok		7
	Up		8
	Down		9
	Right		0
	Left		AV
	Red		SP/LP
	Green		Play
	Yellow		>>
			Blue
			Info
			Text
			1
			2
			3
			4
			5
			6
			7
			8
			9
			0
			AV
			Media
			Play
			>>





Original		Replacement		Original		Replacement	
	<<		<<				
	Stop		Stop				
	Pause		Pause				
	Rec		Rec				
	Mark		3D				
	0000		Guide				











Original	Replacement	Original	Replacement
Power	Power	Blue/[ ]	Blue
Vol+	Vol +	Info	Info
Vol-	Vol -	Text	Text
Mute	Mute	Play	Play
PR+	Ch +	Stop	Stop
PR-	Ch -	Rec	Rec
Exit	Exit	Pause	Pause
Menu	Menu	>>	>>
Back	Back	<<	<<
Up	Up	1	1
Down	Down	2	2
Right/Zoom+	Right	3	3
Left/Zoom-	Left	4	4
OK	Ok	5	5
Red/[o]	Red	6	6
Green/Timer/List	Green	7	7
Yellow	Yellow	8	8






























































	Original	Replacement	Original	Replacement
	9			9
	AV			AV
	SP/LP			Media

















Original	Replacement	Original	Replacement
 Power	 Power	 Blue/[ ]	 Blue
 Vol+	 Vol +	 Info	 Info
 Vol-	 Vol -	 Text	 Text
 Mute	 Mute	 1	 1
 PR+	 Ch +	 2	 2
 PR-	 Ch -	 3	 3
 Menu	 Menu	 4	 4
 Exit	 Exit	 5	 5
 Back	 Back	 6	 6
 Up	 Up	 7	 7
 Down	 Down	 8	 8
 Right/Zoom+	 Right	 9	 9
 Left/Zoom-	 Left	 0/-/--	 0
 OK	 Ok	 AV	 AV
 Red/[o]	 Red	 SP/LP	 Media
 Green/Timer/List	 Green	 Play	 Play
 Yellow	 Yellow	 Stop	 Stop





	Original	Replacement	Original	Replacement
	>>		>>	>>
	<<		<<	<<
	Rec		Rec	Rec
	Pause		Pause	Pause
	Mark		3D	3D
	0000		GUIDE	GUIDE

