




































































































Original	Replacement	Original	Replacement
 Power	 Power	 EPG	 Guide
 Mute	 Mute	 Menu	 Menu
 Format	 Format	 Info	 Info
 SAT	 Smart	 Up	 Up
 TV/STB	 Media	 Down	 Down
 TV/Radio	 TV/R	 Right	 Right
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Vol+	 Vol +
 4	 4	 Vol-	 Vol -
 5	 5	 Exit	 Exit
 6	 6	 CH+ />>>I	 Ch +
 7	 7	 CH- /I<<<	 Ch -
 8	 8	 Red/Text	 Red
 9	 9	 Green/Audio	 Green
 0	 0	 Yellow/Sub.T	 Yellow
 Back	 Back	 Blue/Find	 Blue

Original	Replacement	Original	Replacement
 Power	 Power	 EPG	 Guide
 Mute	 Mute	 Menu	 Menu
 Format	 Format	 Info	 Info
 SAT	 Smart	 Up	 Up
 TV/STB	 Media	 Down	 Down
 TV/Radio	 TV/R	 Right	 Right
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Vol+	 Vol +
 4	 4	 Vol-	 Vol -
 5	 5	 Exit	 Exit
 6	 6	 CH+ />>>I	 Ch +
 7	 7	 CH- /I<<<	 Ch -
 8	 8	 Red/Text	 Red
 9	 9	 Green/Audio	 Green
 0	 0	 Yellow/Sub.T	 Yellow
 Back	 Back	 Blue/Find	 Blue





	Original	Replacement	Original	Replacement
	Edit	3D		
	OPT	Options		
	USB/PVR	AV		
	FAV	Pre Ch		
	<<	<<		
	Play	Play		
	Pause	Pause		
	>>	>>		
	Stop	Stop		
	Pg Down	I<<		
	Pg Up	>>I		
	Rec	Rec		

