






















































































| Original | | Replacement | | Original | | Replacement | |
|---|-------|---|-------------------|---|-------------|---|------------------------------|
|  | Power |  | Power |  | V- |  | Vol- |
|  | Input |  | AV / Input / RDS |  | Home |  | Menu / Home |
|  | 1 |  | 1 |  | P- |  | CH- / Page- |
|  | 2 |  | 2 |  | [G] |  | Guide / EPG / -/-- |
|  | 3 |  | 3 |  | i |  | Info / Angle |
|  | 4 |  | 4 |  | Up |  | Up |
|  | 5 |  | 5 |  | Left |  | Left |
|  | 6 |  | 6 |  | OK |  | OK |
|  | 7 |  | 7 |  | Right |  | Right |
|  | 8 |  | 8 |  | Back |  | Back / Return |
|  | 9 |  | 9 |  | Down |  | Down |
|  | Lang |  | Audio / Lang I/II |  | Exit |  | Exit / Cancel / Clear |
|  | 0 |  | 0 |  | Netflix |  | Shift + Red / Netflix / |
|  | TXT |  | Text / Goto |  | YouTube |  | Shift + Yellow / YouTube / |
|  | V+ |  | Vol+ |  | prime video |  | Shift + Blue / Prime |
|  | Mute |  | Mute / Dimmer |  | Rakuten Tv |  | TV/Radio / |
|  | P+ |  | CH+ / Page+ |  | twitch |  | Shift + Green / APP / Repeat |





| Original | | Replacement | |
|--|--------|--|-----------------------------|
|  | *1 |  | Setup / OPT / |
|  | Red |  | Red / Netflix / Search |
|  | Green |  | Green / APP / Repeat |
|  | Yellow |  | Yellow / YouTube / Repeat |
|  | Blue |  | Blue / Prime Video / Random |
|  | << |  | << / Tune- |
|  | Pause |  | Pause / Step / Freeze |
|  | >> |  | >> / Tune+ |
|  | Rec |  | Rec / Rec Mode |
|  | Play |  | Play / Slow |
|  | Stop |  | Stop / Hold |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Replacement | |
|----------|--|-------------|--|
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

