






















































































| Original | Replacement |
|--|---|
|  Power |  Power |
|  Pop Up |  D. Menu |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  Mute |  Mute |
|  CH+ |  Ch + |
|  CH- |  Ch - |
|  Top Menu |  Menu |
|  I<< |  I<< |
|  >>I |  >>I |
|  << |  << |
|  >> |  >> |
|  Stop |  Stop |
|  Play |  Play |
|  Pause |  Pause |
|  Back |  Back |
|  Up |  Up |

| Original | Replacement |
|--|--|
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK |  Ok |
|  [:::] |  Guide |
|  Red/Program |  Red |
|  Green/Bookmar |  Green |
|  Yellow/Thumbnail |  Yellow |
|  Blue/Zoom |  Blue |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |



















| Original | Replacement |
|--|--|
|  Power |  Power |
|  Eject |  Eject |
|  Disc |  1 |
|  HDMI1/Roku |  2 |
|  HDMI2 |  3 |
|  HDMI3/Aple |  4 |
|  Bluetooth |  5 |
|  AUX |  6 |
|  TV |  7 |
|  Radio |  TV/R |
|  Pop Up |  D. Menu |
|  Display |  Info |
|  Top Menu |  Menu |
|  Surround |  Dual |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  Mute |  Mute |


| Original | Replacement |
|--|---|
|  CH+ |  Ch + |
|  CH- |  Ch - |
|  I<< |  I<< |
|  >>I |  >>I |
|  << |  << |
|  >> |  >> |
|  Play |  Play |
|  Stop |  Stop |
|  Pause |  Pause |
|  Recall |  Pre Ch |
|  (10) |  Media |
|  [::] |  Guide |
|  Home |  Smart |
|  *≡ |  Options |
|  Back |  Back |
|  Up |  Up |
|  Down |  Down |




































| Original | Replacement | Original | Replacement |
|--|--|----------|-------------|
|  Right |  Right | | |
|  Left |  Left | | |
|  OK |  Ok | | |
|  Red/program |  Red | | |
|  Green/Bookmar |  Green | | |
|  Yellow/Thumbnail |  Yellow | | |
|  Blue/Zoom |  Blue | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |





| | Original | Replacement | Original | Replacement |
|---|----------|---|----------|-------------|
|  | Power |  | | |
|  | Pop Up |  | | |
|  | Play |  | | |
|  | >> |  | | |
|  | << |  | | |
|  | Pause |  | | |
|  | Stop |  | | |
|  | OK |  | | |
|  | Up |  | | |
|  | Down |  | | |
|  | Right |  | | |
|  | Left |  | | |
|  | Vol+ |  | | |
|  | Vol- |  | | |
|  | Mute |  | | |
| | | | | |
| | | | | |





| Original | Replacement |
|------------------|-------------|
| Power Tv | Power |
| Eject | Eject |
| Pop Up | D. Menu |
| Vol+ | Vol + |
| Vol- | Vol - |
| Mute | Mute |
| Recall | Back |
| Up | Up |
| OK | Ok |
| Down | Down |
| Right | Right |
| Left | Left |
| Red/Program | Red |
| Green/Bookmar | Green |
| Yellow/Thumbnail | Yellow |
| Blue/Zoom | Blue |
| CH+ | Ch + |

| Original | Replacement |
|----------|-------------|
| CH- | Ch - |

