







































































| Original  |          | Replacement   |                           | Original  |       | Replacement   |                       |
|---|----------|---|---------------------------|---|-------|---|-----------------------|
|    | Power    |    | Power                     |    | Menu  |    | Menu / Home           |
|    | Mute     |    | Mute / Dimmer             |    | Exit  |    | Exit / Cancel / Clear |
|    | Nicam/A2 |    | Shift + Audio / Lang I/II |    | 1     |    | 1                     |
|    | Sleep    |    | Sleep / Timer             |    | 2     |    | 2                     |
|    | Aspect   |    | Zoom / Size               |    | 3     |    | 3                     |
|    | USB/CR   |    | Shift + 8                 |    | 4     |    | 4                     |
|    | Display  |    | Display / Media           |    | 5     |    | 5                     |
|    | Auto     |    | Smart / List              |    | 6     |    | 6                     |
|    | PMode    |    | Picture / Format          |    | 7     |    | 7                     |
|    | SMode    |    | Sound / Title             |    | 8     |    | 8                     |
|   | DTV      |   | D.Menu / Top              |   | 9     |   | 9                     |
|  | Source   |  | AV / Input / RDS          |  | 0     |  | 0                     |
|  | Up       |  | Up                        |  | -/-   |  | Guide / EPG / -/-     |
|  | Left     |  | Left                      |  | Back  |  | Back / Return         |
|  | Enter    |  | OK                        |  | CH+   |  | CH+ / Page+           |
|  | Right    |  | Right                     |  | Info  |  | Info / Angle          |
|  | Down     |  | Down                      |  | Audio |  | Audio / Lang I/II     |





| Original |            | Replacement |                        |
|----------|------------|-------------|------------------------|
|          | Vol+       |             | Vol+                   |
|          | CH-        |             | CH- / Page-            |
|          | FAV        |             | Fav / Marker / PC      |
|          | Tv/Radio   |             | TV/Radio /             |
|          | Vol-       |             | Vol-                   |
|          | Text       |             | Text / Goto            |
|          | Play       |             | Play / Slow            |
|          | Pause      |             | Pause / Step / Freeze  |
|          | Stop/EPG   |             | Stop / Hold            |
|          | Subtitle   |             | Subtitle / EQ          |
|          | Rec/Hold   |             | Rec / Rec Mode         |
|          | <</Index   |             | << / Tune-             |
|          | >>/Size    |             | >> / Tune+             |
|          | I<</Reveal |             | I<< / Preset-          |
|          | >>I/Sbpage |             | >>I / Preset+          |
|          | Red        |             | Red / Netflix / Search |
|          | Green      |             | Green / APP / Repeat   |

| Original |        | Replacement |                             |
|----------|--------|-------------|-----------------------------|
|          | Yellow |             | Yellow / YouTube / Repeat   |
|          | Cyan   |             | Blue / Prime Video / Random |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |
|          |        |             |                             |

