

























































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	Prog+		Ch +
	Prog-		Ch -
	[≡]/TXT		Text
	[+]/Display		Info
	Tv/DVB-T		Smart
	[]/Line		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Shift + Guide
	PRE		Pre Ch
	Up/P+		Up
	Down/P-		Down
	Right/Vol+		Right
	Left/Vol-		Left
	[II]/Tv Menu		Menu
	-IXI-/Exit		Exit
	Sleep		Shift + Power
	-I/I-/P.STD		Shift + Format
	-I/I-/S.STD		Shift + Dual
	[<>]/P.Size		Format
	Open/Close		Eject
	Rec		Rec





Original	Replacement	Original	Replacement
	 Stop		 Dual
	 Play		 Subt
	 Pause		 Options
	 <<		 TV/R
	 >>		 Shift + Ch -
	 l<<		 Shift + Ch +
	 >>l		 Guide
	 Red		 3D
	 Green		 Back
	 Yellow		 AV
	 Blue		 Ok
	 Shift + 3D		
	 Shift + AV		
	 Shift + TV/R		
	 Shift + Subt		
	 Shift + Text		
	 Shift + Info		

