







































































Original	Replacement	Original	Replacement
 Power	 Power	 Red	 Red
 Source	 AV	 Green	 Green
 Picture	 Format	 Yellow	 Yellow
 Sound	 Shift + Dual	 Blue	 Blue
 Mute	 Mute	 Up	 Up
 1	 1	 Down	 Down
 2	 2	 Right	 Right
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 CH+	 Ch +
 6	 6	 CH-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 EPG/Size	 Guide
 0	 0	 Subtitle/Index	 Subt
 Menu	 Menu	 Sleep/Hold	 Sleep
 Exit	 Exit	 Text	 Text

Original	Replacement	Original	Replacement
 Red	 Red	 TV	 AUX
 Green	 Green	 DVD	 MUTE
 Yellow	 Yellow	 SAT	 SHIFT
 Blue	 Blue	 PLAY MODE	 REC MODE
 Up	 Up	 Play	 Pause
 Down	 Down	 Stop	 Red dot
 Right	 Right	 FF	 FR
 Left	 Left	 SOUND	 AD
 OK	 Ok	 SETTINGS	 OPT
 CH+	 Ch +	 LIST	 DUAL
 CH-	 Ch -	 SUBT	 PICTURE
 Vol+	 Vol +	 PROG	 ECO
 Vol-	 Vol -	 SLEEP	 TV/R
 EPG/Size	 Guide	 FORMAT	 3D
 Subtitle/Index	 Subt	 E-MANUAL	 REPEAT
 Menu	 Menu	 ZOOM	 TIMER
 Sleep/Hold	 Sleep	 D.MENU	 TEXT
 Text	 Text	 TOP MENU	 DISPLAY





Original	Replacement	Original	Replacement
 FAV/Sub.Code	 Pre Ch		
 Tv/Reveal	 TV/R		
 Comp/Mix	 Options		
 Lang/Cancel	 Dual		
 Info	 Info		
 Recall	 Back		
 I/II	 List		
 Zoom	 Eject		
 DMP	 Smart		
 Play	 Play		
 Pause	 Pause		
 Stop	 Stop		
 Display/DMP	 3D		
 <<	 <<		
 >>	 >>		
 I<<	 I<<		
 >>I	 >>I		

