



Original	Replacement	Original	Replacement
	 Power		 Up
	 1		 Left
	 2		 OK
	 3		 Right
	 4		 Down
	 5		 Red / Netflix / Search
	 6		 Mute / Dimmer
	 7		 Green / APP / Repeat
	 8		 AV / Input / RDS
	 9		 Yellow / YouTube / Repeat
	 Menu / Home		 TV/Radio /
	 0		 Blue / Prime Video / Random
	 Guide / EPG / -/--		 Text / Goto
	 Vol-		
	 Vol+		
	 CH- / Page-		
	 CH+ / Page+		

Original	Replacement	Original	Replacement
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			
			

