


























Original	Replacement
Power	Power
TV/RAD	TV/R
Bollywood	Format
[↔]/Ratio	3D
Away/Mosquito	Media
Source	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
List	List

Original	Replacement
Info	Info
Vol+	Vol +
Vol-	Vol -
Mute	Mute
FAV	Pre Ch
Guide	Guide
P+	Ch +
P-	Ch -
Back	Back
Exit	Exit
Home	Smart
*	Menu
Q.Menu	D. Menu
Text	Text
T.OPT	Options
Up	Up
Down	Down





Original	Replacement	Original	Replacement
	Right		Right
	Left		Left
	OK		Ok
	AD/*		Subt
	Rec		Rec
	Stop/Live TV		Stop
	<<		<<
	Play		Play
	Pause		Pause
	>>		>>
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue

