















































































































Original	Replacement	Original	Replacement
	Power		Power
	Open/Close		Eject / Surround
	Function		Smart / List
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Clear		Exit / Cancel / Clear
	0		0
	Repeat		Shift + Green / APP / APP /
	I<<		I<< / Preset-
	<<		<< / Tune-
	>>		>> / Tune+
	>>I		>>I / Preset+
	Stop		Stop / Hold
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Speaker Level		TV/Radio /
	Vol+		Vol+
	Optical / Tv Sound		Setup / OPT /
	Sound Effect		Sound / Title
	Vol-		Vol-
	Mute		Mute / Dimmer
	Home		Menu / Home
	3D Sound		Zoom / Size
	Info/Menu		Info / Angle
	Up/Presets+		Up
	Left/Tuning-		Left
	Enter		OK





Original	Replacement
 Right/Tuning+	 Right
 Down/Presets-	 Down
 Back	 Back / Return
 Title/Pop Up	 Picture / Format
 Disc Menu	 D.Menu / Top
 Red/RDS	 Red / Netflix / Search
 Green/PTY	 Green / APP / Repeat
 Yellow/PTY Search	 Yellow / YouTube / Repeat
 Blue/Mono/Stereo	 Blue / Prime Video / Random
 Subtitle	 Subtitle / EQ
 Audio	 Audio / Lang I/II
 Sleep	 Sleep / Timer
 Music ID	 Text / Goto
 *	 Display / Media
 Power Tv	 Shift + Power
 Volum+ Tv	 Shift + Vol+
 PR/CH+ Tv	 CH+ / Page+

Original	Replacement
 AV Input Tv	 AV / Input / RDS
 Volum- Tv	 Shift + Vol-
 PR/CH- Tv	 CH- / Page-

