



























| | Original | Replacement | | Original | Replacement |
|--|--|---|--|----------|-------------|
| |  MC |  1 | | | |
| |  BAND |  6 | | | |
| |  TAPE 1 |  5 | | | |
| |  REC |  Rec / Rec Mode | | | |
| |  MM |  2 | | | |
| |  AUX |  7 | | | |
| |  TAPE 2 |  4 | | | |
| |  MEMORY |  Display / Media | | | |
| |  MUTE |  Mute / Dimmer | | | |
| |  BALANCE L |  Left | | | |
| |  BALANCE R |  Right | | | |
| |  VOL- |  Vol- | | | |
| |  VOL+ |  Vol+ | | | |
| |  PRE AMP |  Smart / List | | | |
| | O1 |  Red / Netflix / Search | | | |
| | O2 |  Green / APP / Repeat | | | |
| | O3 |  Yellow / YouTube / Repeat | | | |

