


















































































| Original | | Replacement | | Original | | Replacement | |
|---|---------|---|---------------|---|------------|---|---------------------------|
|  | Standby |  | Power |  | Stop |  | Stop / Hold |
|  | 1 |  | 1 |  | Play/Pause |  | Play / Slow |
|  | 2 |  | 2 |  | Play/Pause |  | Pause / Step / Freeze |
|  | 3 |  | 3 |  | I>/Resume |  +  | Shift + Play / |
|  | 4 |  | 4 |  | Surround |  | Eject / Surround |
|  | 5 |  | 5 |  | Sound |  | Sound / Title |
|  | 6 |  | 6 |  | Night |  +  | Shift + Sleep / Timer |
|  | 7 |  | 7 |  | Mute |  | Mute / Dimmer |
|  | 8 |  | 8 |  | Repeat |  | Green / APP / Repeat |
|  | 9 |  | 9 |  | Repeat A-B |  | Yellow / YouTube / Repeat |
|  | 0 |  | 0 |  | Sleep |  | Sleep / Timer |
|  | Vol+ |  | Vol+ |  | DIM |  +  | Shift + Mute / Dimmer |
|  | Vol- |  | Vol- |  | Subw + |  | Up |
|  | Left |  | Left |  | Rear + |  +  | Shift + CH+ / |
|  | Right |  | Right |  | Center + |  | CH+ / Page+ |
|  | I<< |  | I<< / Preset- |  | Tv Vol+ |  +  | Shift + Vol+ |
|  | >>I |  | >>I / Preset+ |  | Subw - |  | Down |





| Original | Replacement | Original | Replacement |
|--|---|----------|-------------|
|  Rear - |  Shift + CH- / | | |
|  Center - |  CH- / Page- | | |
|  Tv Vol- |  Shift + Vol- | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |





































| Original | Replacement | Original | Replacement |
|----------|--------------|----------|----------------|
| | Standby | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | Disc (DVD) | | D.Menu / Top |
| | 0 | | 0 |
| | Vol+ | | Vol+ |
| | System (DVD) | | Menu / Home |
| | Vol- | | Vol- |
| | I<< | | I<< / Preset- |
| | >>I | | >>I / Preset+ |
| | Stop | | Stop / Hold |
| | Play/Pause | | Play / Slow |
| | I>/Resume | | Shift + Play / |





| Original | | Replacement | | Original | | Replacement | |
|---|---------|---|-------|----------|--|-------------|--|
|  | Standby |  | Power | | | | |
|  | 1 |  | 1 | | | | |
|  | 2 |  | 2 | | | | |
|  | 3 |  | 3 | | | | |
|  | 4 |  | 4 | | | | |
|  | 5 |  | 5 | | | | |
|  | 6 |  | 6 | | | | |
|  | 7 |  | 7 | | | | |
|  | 8 |  | 8 | | | | |
|  | 9 |  | 9 | | | | |
|  | 0 |  | 0 | | | | |
|  | Up |  | Up | | | | |
|  | Left |  | Left | | | | |
|  | OK |  | OK | | | | |
|  | Right |  | Right | | | | |
|  | Down |  | Down | | | | |





| Original | Replacement |
|---|---|
|  Standby |  Power |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |

| Original | Replacement |
|----------|-------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

