












































































Original	Replacement
 Power	 Power
 Eject	 Eject / Surround
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 OSD / Info	 Display / Media
 OSD / Info	 Info / Angle
 4	 4
 5	 5
 6	 6
 V-Mode	 Picture / Format
 7	 7
 8	 8
 9	 9
 P/N / Fav	 Fav / Marker / PC
 0	 0

Original	Replacement
 10+	 Shift + Guide / EPG / -/-
 Goto	 Shift + Text /
 Setup	 Setup / OPT /
 Angle	 Shift + Info / Angle
 Text / Title	 Sound / Title
 Text / Title	 Text / Goto
 Subtitle	 Subtitle / EQ
 Menu	 Menu / Home
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Down	 Down
 PBC / EPG	 Guide / EPG / -/-
 Source	 AV / Input / RDS
 Exit	 Exit / Cancel / Clear
 <<	 << / Tune-





Original	Replacement
 Play / Pause	 Play / Slow
 Play / Pause	 Pause / Step / Freeze
 I<<	 I<< / Preset-
 >>	 >> / Tune+
 Stop	 Stop / Hold
 >>I	 >>I / Preset+
 Red / Prog	 TV/Radio /
 Red / Prog	 Red / Netflix / Search
 Green / Step	 Green / APP / Repeat
 Green / Step	 Shift + Pause / Step /
 Yellow / Repeat	 Yellow / YouTube / Repeat
 Yellow / Repeat	 Shift + Green / APP /
 Blue / A-B	 Blue / Prime Video / Random
 Blue / A-B	 Shift + Yellow / YouTube /
 Zoom	 Zoom / Size
 Slow	 Shift + Play /
 Vocal	 D.Menu / Top

Original	Replacement
 Audio	 Audio / Lang I/II
 CH-	 CH- / Page-
 CH+	 CH+ / Page+
 Vol-	 Vol-
 Vol+	 Vol+

