























































| Original | Replacement | Original | Replacement |
|------------|---|-------------|---|
| On/Off |  Power | Top Menu |  D.Menu / Top |
| Audio Off |  Mute / Dimmer | Setup |  Setup / OPT / |
| Play |  Play / Slow | C/CH |  Text / Goto |
| Pause |  Pause / Step / Freeze | DVD/TV |  AV / Input / RDS |
| Stop |  Stop / Hold | Menu |  Menu / Home |
| Record |  Rec / Rec Mode | Menu Up |  Up |
| Rewind |  << / Tune- | Angle |  Info / Angle |
| F.Forward |  >> / Tune+ | Menu Left |  Left |
| Prev. |  I<< / Preset- | OK Enter |  OK |
| Next |  >>I / Preset+ | Menu Right |  Right |
| Title |  Sound / Title | Clear/00:00 |  Exit / Cancel / Clear |
| Lang |  Audio / Lang I/II | Menu Down |  Down |
| Subt. |  Subtitle / EQ | Return |  Back / Return |
| Open/Close |  Eject / Surround | Volume+ |  Vol+ |
| Resume |  Picture / Format | Auto/Track |  Smart / List |
| Zoom |  Zoom / Size | Slow Up |  CH+ / Page+ |
| Progr. |  TV/Radio / | Volume- |  Vol- |



| Original | Replacement | Original | Replacement |
|--------------|---|----------|---|
| Display |  Display / Media | Np |  Blue / Prime Video / Random |
| Slow Down |  CH- / Page- | 3D |  +  Shift + 3 |
| 1 |  1 | | |
| 2 |  2 | | |
| 3 |  3 | | |
| 4 |  4 | | |
| 5 |  5 | | |
| 6 |  6 | | |
| 7 |  7 | | |
| 8 |  8 | | |
| 9 |  9 | | |
| +10 |  Guide / EPG / -/-- | | |
| 0 |  0 | | |
| Pbc |  Fav / Marker / PC | | |
| R/L |  Red / Netflix / Search | | |
| Repeat/1/All |  Green / APP / Repeat | | |
| Rep/A-B |  Yellow / YouTube / Repeat | | |

