



Original	Replacement
	Power
	Mute
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	Tv/Radio
	←PR
	EPG
	Menu
	Info

Original	Replacement
	Exit
	Up
	Down
	Ok
	Right
	Left
	Vol +
	Vol -
	Ch +
	Ch -
	Pause
	3D
	Pre Ch
	Smart
	Format
	AV
	Red





Original	Replacement	Original	Replacement
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Audio	 Dual		
 TXT	 Text		
 [...]	 Subt		
 Audio L/R	 +  Shift + Dual		

