







































































| Original | Replacement |
|---|--|
|  Power |  Power |
|  Mute |  Mute |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  DTV/ATV |  Info |
|  Recall |  Pre Ch |
|  P.Mode |  Shift + Format |
|  S.Mode |  Shift + Dual |
|  Sleep |  Sleep |

| Original | Replacement |
|--|---|
|  Menu |  Menu |
|  Source |  AV |
|  Enter |  Ok |
|  Up |  Up |
|  Down |  Down |
|  Left |  Left |
|  Right |  Right |
|  Exit |  Exit |
|  Display |  Shift + Info |
|  Vol+ |  Vol + |
|  Vol- |  Vol - |
|  CH+ |  Ch + |
|  CH- |  Ch - |
|  MTS |  Shift + Sleep |
|  Rec List |  D. Menu |
|  FAV/List |  Dual |
|  Rec |  Rec |



