







































































Original	Replacement	Original	Replacement
 Power	 Power	 Down	 Down
 Mute	 Mute	 Right	 Right
 1	 1	 Left	 Left
 2	 2	 Prog+	 Ch +
 3	 3	 Prog-	 Ch -
 4	 4	 Vol+	 Vol +
 5	 5	 Info	 Info
 6	 6	 EPG	 Guide
 7	 7	 Menu	 Menu
 8	 8	 Red/A	 Red
 9	 9	 Green/B	 Green
 0	 0	 Yellow/C	 Yellow
 -/--	 Shift + Guide	 Blue/D	 Blue
 Recall	 Pre Ch	 Sleep	 Sleep
 Source	 AV	 Cancel	 Shift + Back
 OK	 Ok	 TXT	 Text
 Up	 Up	 Size	 Dual





Original		Replacement		Original		Replacement	
	Hold		Back				
	Reveal		D. Menu				
	Mix		Eject				
	Index		List				
	Subpage		Options				
	Subtitle		Subt				
	Texe		TV/R				
	Fav		Shift + Pre Ch				
	Format		Format				
	Vol-		Vol -				
	P Mode		I<<				
	S Mode		>>I				
	MTS		Stop				
	3DNR		Pause				

