



Original	Replacement
 Power	 Power
 [...] / Text	 Text / Goto
 Guide	 Guide / EPG / /-/-
 Zz/Sleep	 Sleep / Timer
 Stop	 Stop / Hold
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Source	 AV / Input / RDS
 [<>] / Format	 Picture / Format
 [i] / Info	 Info / Angle
 Home	 Menu / Home
 P≡P / Swap	 Fav / Marker / PC
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down

Original	Replacement
 Back	 Back / Return
 CH-	 CH- / Page-
 CH+	 CH+ / Page+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 Vol+	 Vol+
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7



